

# **POLYFIBROBLAST: A SELF-HEALING AND GALVANIC PROTECTION ADDITIVE**

*Progress Report #7*

Prepared for:

**Clifford W. Anderson**  
**Logistics S&T Thrust Manager**  
**Office of Naval Research**  
Code 30, Room 1149  
875 North Randolph Street  
Arlington, VA 22203-1995

Prepared by:

**Jason J. Benkoski, Ph.D., Senior Research Scientist**  
**The Johns Hopkins University Applied Physics Laboratory**  
**The Milton S. Eisenhower Research Center**  
11100 Johns Hopkins Rd, MS 21-N109  
Laurel, MD 20723  
Tel. (240) 228-5140

Reporting Period: June 27 2011 through July 25, 2011  
Date of Report: July 25, 2011

**20110729184**

REPORT DOCUMENTATION PAGE				Form Approved OMB No. 0704-0188	
<small>The public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing the burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.</small> <b>PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.</b>					
1. REPORT DATE (DD-MM-YYYY) 07-25-2011		2. REPORT TYPE Performance/Technical Report (Monthly)		3. DATES COVERED (From - To) 6/27/2011 - 7/25/2011	
4. TITLE AND SUBTITLE  Polyfibroblast: A Self-Healing and Galvanic Protection Additive				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER N00014-09-1-0383	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)  Benkoski, Jason, J.				5d. PROJECT NUMBER	
				5e. TASK NUMBER FGY25	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) The Johns Hopkins University Applied Physics Laboratory 11100 Johns Hopkins Rd Laurel, MD 20723				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) Office of Naval Research 875 North Randolph Street Arlington, VA 22203-1995				10. SPONSOR/MONITOR'S ACRONYM(S) ONR	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for Public Release: distribution is Unlimited.					
13. SUPPLEMENTARY NOTES					
14. ABSTRACT The goal of this project is to develop a primer additive that mimics the self-healing ability of skin by forming a polymer scar across scratches. Designed to work with existing military grade primers, Polyfibroblast consists of microscopic, hollow zinc tubes filled with a moisture-cured polyurethane-urea (MCPU). When scratched, the foaming action of a propellant ejects the resin from the broken tubes and completely fills the crack. No catalysts or curing agents are needed since the polymerization is driven by ambient humidity.					
15. SUBJECT TERMS corrosion protection, self-healing, coatings, polymers					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT		18. NUMBER OF PAGES
a. REPORT	b. ABSTRACT	c. THIS PAGE	UU		6
U	U	U			19a. NAME OF RESPONSIBLE PERSON Jason J Benkoski
					19b. TELEPHONE NUMBER (Include area code) 240-228-5140

## TABLE OF CONTENTS

<b>1</b>	<b>SUMMARY</b>	<b>3</b>
<b>2</b>	<b>PROJECT GOALS AND OBJECTIVES</b>	<b>3</b>
<b>3</b>	<b>KEY ACCOMPLISHMENTS</b>	<b>3</b>
3.1	SILANE FORMULATION PROCESSABILITY	3
3.2	ZINC DUST FILLER	4
3.3	PROCESSING METHODOLOGY	5
<b>4</b>	<b>NEXT STEPS</b>	<b>6</b>
4.1	PPG: SCALE-UP, DRYING, AND CHARACTERIZATION	6
4.2	APL: SILANE OPTIMIZATIONS	6



## 1 Summary

This month marked the transition to a pair of new strategies for improving the corrosion protection afforded by Polyfibroblast. With respect to self-healing, we screened a large number of silane-enhanced recipes for processability. With respect to galvanic protection, we blended zinc dust with solid polymer spheres to determine whether the packing mismatch impaired the ability to cathodically protect steel. We rounded out the month by exploring advances in drying that could potentially bring down processing costs and enhance scalability.

## 2 Project Goals and Objectives

Work continues to improve the corrosion protection performance through the end of the year. The more immediate tasks, however, involve the two remaining milestones: (1) shelf life will be sufficient to survive one week at 100°F and 100% relative humidity without loss of liquid volume fraction by mid August, and (2) PPG will demonstrate the capability to synthesize enough Polyfibroblast filler to make 1-gallon batches of primer by early September.

## 3 Key Accomplishments

### 3.1 Silane Formulation Processability

Silane coupling agents may be added to the existing microcapsules either in low concentrations, in which they serve primarily as a wetting agent for the polyurea, or in high concentrations, in which they form the primary moisture barrier layer. The choice for the final formulation depends in large measure on the one that provides the best corrosion potential, but it is constrained by the need to form stable microcapsules. To this end, we explored a number of recipes in which the following silane coupling agents were substituted for isophorone diisocyanate (IPDI) in varying concentrations ranging from 1 to 70%

- Octadecyltrimethoxy silane (OTS)
- Isocyanatopropyltrimethoxy silane (ITS).
- Glycidoxypentyltrimethoxy silane (GPS)

As expected, the lowest concentrations most readily formed stable microcapsules. The more polar silanes (ITS and GPS), in particular, could not be microencapsulated above 5% (w/w) silane. This finding is not surprising, and likely results from the polar silane molecules segregating to the interface, where they prevent the formation of a dense polymer skin layer.

OTS has been shown to encapsulate up to 20% (w/w) with no issues. At 70% OTS, the isocyanate monomers are no longer completely miscible with the OTS. This issue has been addressed by substituting poly(phenylene isocyanate) (PPI) with toluene diisocyanate (TDI), which allows microencapsulation to occur.

**Table 1:** Table summarizing the different attempts to incorporate silane coupling agents into microcapsules. Notably, GPS and ITS could not be encapsulated above a concentration of 5% (w/w). OTS incorporated more readily, but required formulation changes above 50% OTS to address miscibility issues with the isocyanate monomers at those concentrations.

---

Formulation						Description of Microcapsules
Silane Type	% Silane	Silane (g)	IPDI (g)	MIL-P (g)	PPI (g)	
GPS	1	0.2	16.8	1	2	Well formed microcapsules, which had a liquid interior. Pass
GPS	5	1.0	16.0	1	2	Well formed microcapsules, which had a liquid interior. Pass
GPS	10	2.0	15.0	1	2	Poorly formed microcapsules with no liquid interior. Fail
GPS	20	4.0	13.0	1	2	Microcapsules never settled and the solution turned into a foam. Fail
GPS	50	10.0	7.0	1	2	Microcapsules never settled and the solution turned into a foam. Fail
GPS	70	14.0	3.0	1	2	Microcapsules never settled and the solution turned into a foam. Fail
ITS	1	0.2	16.8	1	2	Well-formed microcapsules with noticeable internal structure. Pass
ITS	5	1.0	16.0	1	2	Well formed microcapsules, which had a liquid interior. Pass
ITS	10	2.0	15.0	1	2	Microcapsules never settled and the solution turned into a foam. Fail
ITS	20	4.0	13.0	1	2	Well-formed microcapsules, but with no liquid interior. Fail
ITS	50	10.0	7.0	1	2	Poorly formed microcapsules with no liquid interior. Fail
ITS	70	14.0	3.0	1	2	Poorly formed microcapsules with no liquid interior. Fail
OTS	1	0.2	16.8	1	2	Well-formed microcapsules with noticeable internal structure. Pass
OTS	5	1.0	16.0	1	2	Well-formed microcapsules with noticeable internal structure. Pass
OTS	10	2.0	15.0	1	2	Well-formed microcapsules with noticeable internal structure. Pass
OTS	20	4.0	13.0	1	2	Well-formed microcapsules with noticeable internal structure. Pass
OTS	50	10.0	7.0	1	2	Well-formed microcapsules with noticeable internal structure. Pass
OTS	70	14.0	3.0	1	2	PPI was not soluble in the OTS. Microcapsules reaction was halted. Fail

### 3.2 Zinc Dust Filler

Perhaps the greatest technical challenge facing this program in FY11 has been the need to reach levels of galvanic protection that are achieved by off-the-shelf zinc-rich primers. Despite our ability to heal scratches up to 1/8<sup>th</sup> in., some incomplete healing is unavoidable. These regions corrode at a faster rate than comparable scratches in a zinc-rich primer. Previous electrochemical characterization of the Ni/Zn shell of Polyfibroblast showed that while the alloy afforded some galvanic protection, the protection was temporary.

Rather than pouring resources into further Ni/Zn alloy development, a better approach was to substitute some fraction of Polyfibroblast microcapsules for zinc dust instead. The zinc dust approach overcomes the main limitations of relying solely upon the Ni/Zn shell for galvanic protection:


1. Electroless plating may not physically allow sufficiently high zinc concentrations to avoid the reversal of polarization at long times.
2. While electroless plating is practical for thin films at the pilot scale, it may not be economically sensible for generating tons of bulk sacrificial zinc.
3. Substituting zinc dust for the microcapsules even brings down the cost due to the polymer component of the microcapsule.

The largest initial concern with blending zinc dust and microcapsules is that the microcapsules will interfere with the packing of the zinc dust. To this end, we blended zinc dust with fully cured, solid polymer microcapsules with no metallic shell. The overall filler loading was fixed at 55% (vol/vol), the critical pigment volume concentration (CPVC). Within that 55%, the volume fraction of zinc powder was adjusted from 25% to 90%.

The solid spheres neither provide self-healing capability nor galvanic protection, and in this case, they do not even provide electrical conductivity. The goal of this experiment is to see if the 37  $\mu$ m polymer spheres prevent the 7  $\mu$ m zinc particles from forming a fully percolated network. If percolation is disrupted, it will be manifested as a reduction in the overall galvanic protection



capacity. Poorly packed zinc dust will no longer act as a single, large sacrificial anode, but rather as individual particles or small clusters, which will be more quickly consumed.




**Figure 1:** Moisture resistance data for primers formed with zinc dust and uncoated polymer spheres. Galvanic protection was most effective for small scratches, but it was independent of zinc dust fraction.

Figure 1 shows that galvanic protection was most effective in the thinnest scratches. The performance in the wider scratches was actually inferior to the self-healing microcapsules. However, the overall corrosion protection was independent of the ratio of zinc particles to polymer particles. Although this data suggests that the smaller zinc particles have no problem packing around the larger polymer spheres, the relatively poor performance in the larger scratches seems to indicate that perhaps the total filler loading was below the CPVC. These experiments will be repeated for a higher overall loading of filler material.

### 3.3 Processing Methodology

Spray drying was successfully tested at PPG on fully cured polymer spheres, as shown in Figure 2. The Buchi B-191 mini spray dryer operates by spraying a microcapsule slurry as a fine mist at 80°C. The high surface area of the droplets and elevated temperature serve to remove water before the microcapsules hit the ground. Moving forward, the main technical challenge is to limit the breakage of microcapsules during pumping, and to limit unwanted curing that might be expected in water at 80°C.



**Figure 2:** (left) Bruchi B-191 mini spray dryer. (right) Free flowing solid microcapsules ( $\sim 37\mu\text{m}$  diameter) dispersed by spray drying.

## 4 Next Steps

### 4.1 PPG: Scale-Up, Drying, and Characterization

PPG has little over one month remaining to prepare for the final 1-gallon scale-up. Their exploration of alternative drying methods ties in to the scale-up effort, since freeze-drying the larger batch may not be possible. Finally, PPG will continue to characterize panels prepared at APL as needed.

### 4.2 APL: Silane Optimizations

In addition to continuing work on silane formulations and zinc dust incorporation, APL will also revisit the issue of shelf life by evaluating the current “best practice” microcapsule formulation after one week of exposure to water at  $100^{\circ}\text{F}$ .